


Cabling Management System(CMS) is a comprehensive cabling management software designed to provide users with efficient and reliable cabling solutions. With features such as site management, device management, port management, link management, asset management, drawing management, permission management, and user management. CMS enables users to effectively manage and monitor their cabling systems.

Typical Application



Data Center Application Scenario



Commercial Premises Application Scenario

Where to use



Energy



Bank



Supermarket



Medical



Airport



Education



Industry 4.0



Hotel

Product Features

1. User Login

Input ID, password and verify code to login.



2. Statistic Appearance

This is statistic charts, and you can monitor device usage, asset and work order statistic charts, and operations logs of all logged in users.




3. Project Appearance

In this window, you can view, create, edit project.




4. Unauthorized Access Appearance

In this window, you can view, cancel or confirm all unauthorized access.




5. Work Order Appearance

In this window, you can approve, appoint, reject or withdraw work order, and set process flow of work orders.



6. Template Appearance

In this window, you can maintain all device detail information, including, upload device templates.



7. Drawing Appearance

In this window, you can view, upload or download drawings.



8. Information Query Appearance

In this window, you can query and export all the information.

PROSE Intelligent Cabling System

INFORMATION INQUIRY

Port usage >> By Device

Project Rack Room Rack RackName Device Device Nar Device Type ALL Filter Refresh Export

Project	Rack Room	Rack	Device	Device Type	Total Port Count	Inuse Port Count	Free Port Co
Test Demo	E2	A1_E1_R2	24 Ports Copper Panel	Copper Unit	24	3	21
Test Demo	E2	A1_E1_R2	24 Ports Copper Panel	Copper Unit	24	3	21
Test Demo	E2	A1_E1_R2	Norma 1U Panel(SN LC full)	Fiber Unit	72	0	72
Test Demo	E2	A1_E1_R2	Norma 1U Panel(SN empty)	Fiber Unit	12	0	12
test1	test12	test1-1	SG300-28	Switch	30	0	30
test1	test12	test1-1	DELL R730	Server	5	0	5
test1	test12	test1-1	H3C S5120	Switch	28	0	28
test1	test12	test1-1	48F LCD SM Panel	Fiber Unit	24	0	24
test1	test12	test1-1	4U Taurus Panel_MM pppp ld	Fiber Unit	144	54	90
test1	test12	test1-1	24 Ports Copper Panel	Copper Unit	24	0	24
test1	test12	test1-1	S3048-ON	Switch	52	2	50
test1	1	test-11	24 Ports Copper Panel 11	Copper Unit	24	1	23
test1	1	test-11	DELL R730	Server	5	0	5
test1	1	test-11	WS-C2960S-48TS-L	Switch	52	12	40

Copyright © 2023 Prose

9. Asset Management Appearance

In this window, you can input assets storage information.

PROSE Intelligent Cabling System

ASSETS MANAGEMENT

Assets Management >> Lease

Type ALL Asset Code Asset Code Key Key Lessee Lessee Leasing Company Leasing Co Refresh

Import Export Add

Type	Quantity	Current lease quantity	Pending lease quantity	Graph	Lease Rate
Device	0	0	0	●	0%
Cable	0	0	0	●	0%
Rack	0	0	0	●	0%

Copyright © 2023 Prose

10. Authority Appearance

In this window, you can set authority and user information.

PROSE Intelligent Cabling System

AUTHORITY MANAGEMENT

User

User Name	Email	Sex	Mobile Phone	Account Status	SuperAdmin	App Login	Push Notification	Email Notification	Login Count
admin	admin@host.com	Mr	12	Enabled	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	51
cloris	1@qq.com	Miss		Enabled	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	40
maruf	maruf@prose.com	Mr		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	3
111	app@test.com	Miss		Enabled	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	236
vinodh.b	vinodh.b@prose.in	Mr	12	Enabled	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	3
India	FO@India.com	Mr		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	4
test-01	test-01@qq.com	Miss		Enabled	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	107
app	app@test.com	Miss		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	4
11111111	11111111@qq.com	Miss		Enabled	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	8
Indonesia	FO@Indonesia.com	Mr		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	3
Thailand	FO@Thailand.com	Mr		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2
MiddleEast	FO@MiddleEast.com	Mr		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	1
Philippines	FO@Philippines.com	Mr		Enabled	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	2

Copyright © 2023 Prose

11. System Config Appearance

In this window, you can set port type, the way of database backup, SMTP information and view software Information.

PROSE Intelligent Cabling System

SYSTEM CONFIG

Dictionary >> Device Type

#	Name	Operations
1	Master Unit	<input checked="" type="checkbox"/>
2	Management Unit	<input type="checkbox"/>
3	Copper Unit	<input type="checkbox"/>
4	Fiber Unit	<input type="checkbox"/>
5	Fiber Module	<input type="checkbox"/>
6	Switch	<input type="checkbox"/>
7	Router	<input type="checkbox"/>
8	Server	<input type="checkbox"/>
9	Other	<input type="checkbox"/>

Copyright © 2023 Prose

Benefits of Management Software

1. Provide a complete software based cabling management system (CMS) that stores complete cable records for every element of the ICT cabling system including installed cables, termination components, pathways, patching, cross-connects and test result schedules.
2. Efficient planning, implementation and documentation of network infrastructure provisioning and maintenance activities.
3. Multi-user and allow authenticated access from any point connected to the network via web site or smartphone devices.
4. Improved asset utilization by revealing underutilized ports.
5. Increased network security through continual monitoring for illegal connections.
6. Saves time and cost by enabling remote-access maintenance and troubleshooting.
7. Continually updated inventory of all network assets and graphical representation of precise device locations across multiple sites provides comprehensive information on network structure and resources, enabling enterprise-wide connectivity planning and tracking.
8. Efficient control of work order, makes order delivery process, reduces labor and resource costs.

Minimum Configuration Requirement

Item	Parameter	Technical Specification
Hardware	CPU	≥ 4 (Core) 64bits
	Memory	≥ 16.0GB
	Hard Disk	≥ 500GB
	Ports RJ45	100M/1000M
	Bandwidth	10M
Software	Operation System	Windows Server 2015 or above
	Database	Mysql 5.7 or above
	Web Server	Internet Information Services 8 or above
	Runtime	.Net 4.5.2
	Browser	Google Chrome

Ordering Information

Part Number	Description
CMS-002-01	CMS software of cabling management system (0-2000 ports)
CMS-002-02	CMS software of cabling management system (2001-5000 ports)
CMS-002-03	CMS software of cabling management system (over 5001 ports)


Warranty

1 years of total warranty system guarantee the Cabling Management System.

*Please check the detail warranty documents for more information

While the information has been carefully compiled to the best of our knowledge, nothing is intended as representation or warranty on our part and no statement herein shall be construed as recommendation to infringe existing patents. In the effort to improve our products, we reserve the right to make changes judged to be necessary.

GLOBAL FOOTPRINT



Headquarters

Donauwörth - Germany
PROSE Technologies GmbH
Add.: Dr.-Friedrich-Drechsler-Straße 14, 86609
Donauwörth, Germany
E-mail: info.eu@prosetechnologies.com

Western Europe

Dublin - Ireland
PROSE Technologies (Ireland) Limited
Add.: 6th Floor, South Bank House, Barrow Street,
Dublin 4 Ireland
E-mail: Info@prosetechnologies.com

Eastern Europe & Central Asia

E-mail: info.eeca@prosetechnologies.com

North America

New Jersey - America
PROSE Technologies LLC
Add.: 550 Clark Drive Budd Lake, NJ 07828, United
States of America
Tel: +1 888 840 4066
E-mail: info.us@prosetechnologies.com

Middle East

Dubai - UAE
PROSE Technologies DMCC
Add.: 3702, Mazaya Business Avenue BB2, JLT, Dubai
Tel: +971 4 3999168
E-mail: info.ae@prosetechnologies.com

Africa

Nairobi - Kenya
PROSE Technologies Africa (PTY) Ltd
Tel: +254 780440410
E-mail: info.ke@prosetechnologies.com

Gauteng, (Johannesburg) - South Africa
PROSE Technologies Africa (PTY) Ltd
Add.: Building 20, Cambridge Office Park, 5 Bauhina
Road, Highveld Techno Park Centurion, Gauteng 0169,
South Africa
Mobile: +27 725554840
E-mail: info.za@prosetechnologies.com

South Asia

Mumbai - India
PROSE Technologies India Private Limited
Add.: 403-407, Eco Star, Vishveshwar Nagar,
Goregaon East, Mumbai, India 400063
Tel: +91 22-66453000
E-mail: info.in@prosetechnologies.com

Pune - India
PROSE Technologies India Pvt.Ltd
Add.: A-79, Block-A, Horizon Industrial Parks, Phase II,
MIDC Chakan Industrial Area, Khed, Pune, India
410501
Tel: +91 2135-635200
E-mail: info.in@prosetechnologies.com

Bangalore - India
PROSE Technologies India Private Limited
Add.: No.494 East End Main Road, Jayanagar IX Block,
Bangalore, India 560069
E-mail: info.in@prosetechnologies.com

New Delhi - India
PROSE Technologies India Pvt.Ltd
Add.: H-3/157, 2nd Floor, Vikas Puri, New Delhi, India
110018
E-mail: info.in@prosetechnologies.com

Dhaka - Bangladesh
PROSE Technologies (Bangladesh) Limited
Add.: House-360 (2nd Floor), Lane-5 (East), Baridhara
DOHS, Dhaka-1206, Bangladesh
Tel: +880 1977070130
E-mail: info.bd@prosetechnologies.com

Islamabad - Pakistan
Add.: Unit 514, 5th Floor, ISE Towers, Islamabad,
Pakistan
Tel: +92 3335357733
E-mail: info.pk@prosetechnologies.com

Sri Lanka
Tel: +880 1977070130
E-mail: info.lk@prosetechnologies.com

South East Asia

Selangor - Malaysia
PROSE Technology (M) Sdn. Bhd
Add.: Unit 2-1, Level 2, The Podium, Tower 3, UOA
Business Park, No 1, Jalan Pengaturcara U1/51a,
Seksyen U1, 40150 Shah Alam, Selangor, Malaysia
Tel: +60 126859319
E-mail: info.my@prosetechnologies.com

Bangkok - Thailand
PROSE Technology (Thailand) Co., Ltd
Add.: 349 SJ Infinite I Business Complex, 9 Floor, Room
905, Vibhavadi Rangsit Road, Chom Phon Sun-district,
Chatuchak District, Bangkok Province, Thailand
Tel: +66 80 6606630
E-mail: info.th@prosetechnologies.com

Singapore
PROSE Technologies (Singapore) Pte.Ltd
Add.: 10 Anson Road#13-15 International Plaza
Singapore 079903
Tel: +6598366793
E-mail: info.sg@prosetechnologies.com

Hanoi - Vietnam
PROSE Technologies (Vietnam) Company Limited
Add.: Floor 15, Vinaconex 9 Building, HH-2 Block,
Pham Hung Street, Me Tri Ward, Nam Tu Liem District,
Hanoi, Vietnam
Tel: +84 933086498
E-mail: info.vn@prosetechnologies.com

Taguig - Philippines
PROSE Technologies Philippines, Inc.
Add.: Unit 17 19th Floor Highstreet South Corporate
Plaza Tower 1, 26th Street corner 9th Avenue, Bonifacio
Global City, Taguig City, Philippines
Tel: +63 27572762
E-mail: info.ph@prosetechnologies.com

Jakarta - Indonesia
PT. PROSE Technologies Indonesia
Add.: Plaza Sentral 6th Floor, Jalan Jenderal Sudirman
No. 47, Jakarta 12930, Indonesia
Tel: +62 21 57901997
E-mail: info.id@prosetechnologies.com

East Asia

Suzhou - China
PROSE Technologies (Suzhou) Co.,Ltd
Add.: No. 6, Shen'an Road, DianShanHu, Suzhou,
JiangSu, China
E-mail: Info@prosetechnologies.com

Beijing - China
PROSE Technologies (Beijing) Co.,Ltd
E-mail: Info@prosetechnologies.com

Shanghai - China
PROSE Technologies (Shanghai) Co.,Ltd
E-mail: Info@prosetechnologies.com

Dongguan - China
Add.: Room 1506, building 1, No. 1, Yile Road,
Songshanhu Park, Dongguan City, Guangdong
Province, China
E-mail: Info@prosetechnologies.com

Hongkong - China
PROSE Technologies Company Limited
Add.: Unit B 13/F,Prat Commercial Building, 17-19 Prat
Avenue, Tsimshatsui, Kowloon, HongKong, China
Tel:+86 512 86896789 - 2921/2922
E-mail: info.hk@prosetechnologies.com

Taiwan
Tel: +63 2 7572762
E-mail: info.tw@prosetechnologies.com

Oceania

New South Wales - Australia
PROSE Technologies (Australia) Pty. Ltd
Add.: 5/13 Boundary Rd, Northmead, NSW 2152,
Australia
Tel: +61 2 78055523
E-mail: info.au@prosetechnologies.com